

Layering 102

LLNL-PRES-695078




NIF is moving to a more sustainable operating mode for layering support

- Increased level of training for Cryo Operators and Field Engineers
- New training for Shot Rls on the layering process
- More reliance on Rules of Engagement to make decisions during the layering process
- Reduced off-hours support from layering SMEs

As we transition to this new mode, we want your feedback about how it's working and how we could continue to improve to assure high quality layered experiments

The layering process has four "decision points" where the operators could require input from the experimental team







The changes in the process are in how the decision points are handled if they fall outside of the defined ROE

Before June FM&R

- When developments with a layer are not clearly captured by the ROE, the FE and CSOs contact the SME for review and guidance
 - SMEs are available 24/7
- If the SME feels a decision needs to be made outside the specifications of the ROE, the SME calls for a management review board (MRB)

After June FM&R

- When developments with a layer are not clearly captured by the ROE, the FE and CSOs contact the Shot RI for guidance
- The Shot RI determines whether to call an MRB
- SMEs will be available to consult or to joint the MRB M-F from 7am to 10pm
 - SMEs may be available on weekends, but will no longer be "on call"
- Communications to the Shot RI will be coming from the FEs and CSOs
- The Shot RI may decide to wait to call the MRB during business hours, when the layering SME is on call

Clear and complete Rules of Engagement will be key to the success of this new paradigm



The Layering Group will continue to provide expert, high-quality support of layering activities

- With changes in personnel in the layering group and an increase in the number of layering activities anticipated, it is no longer practical to have dedicated on-call layering SME support during routine layered shot operations
- New procedures and training in are being put in place to enable NIF technicians to handle typical off-normal cases previously referred to the layering SME



Additional notes on facility support for layering after the June FM&R

- For new/unique layering activities (e.g. wetted foam, tentless targets, etc.), more layering SME support will be provided until processes are turned into routine procedures
- Early aborts for layer formation will be limited to
 - Lost seed (~ 1 hour after Form Layer begins)
 - Analysis at 9 hours after Form Layer begins. Standard limb analysis will be performed and layer evaluated against the layer quality ROE.
- Shimming is automated, depends on standard limb analysis



Overview and quick reference to reports




Expected reports from the facility that the Shot RI should be aware of

- Xray QA report warm/cold reports on capsule sag and defects in the image view
- Layer limb analysis reports Low shape, thickness, groove report
- Low Mag imaging report Include possibly large defects in the central portion of the LEH view
- These slides give an overview and background material on the layering process and analysis.



Xray QA report


Xray QA report






Xray QA report: Capsule offset report

Tabs 'WarmQA' or 'ColdQA', show the capsule displacements for each view





Xray QA: Parallax measurement is used to determine location of defects in image ('Parallax – Warm' tab)



Features on side view are often machining burrs on starburst, even though they appear close to capsule

Likely on capsule (closer to capsule than LEH), distance measured from center of capsule. Accuracy is not better than ~ 1-2 mm typically



Xray QA: Most 'dark spots' on the capsule are likely high-Z material

- Detected x-ray spectrum peaks about 8.5 keV
- 30% attenuation corresponds to ~ 1 μm Au, 200 μm HDC, 700 μm CH



Layer Analysis Report

- This summary report comes via email, usually sufficient to decide to keep or reject layer
- Also included is a .zip file which includes more details on the layer analysis, unwrapped images.

C151002-AA-6 LAYER COMPLETION REPORT:

Approved analysis with grooves excised

****** Defects *******

Total standard groove depth = 80.25 um

Total non-standard defect depth = 0.00 um

Largest Defect area = 1261.56 um² from Limb Analysis

 $K_highMag = 1.69 um$

No low mag data reported.

****** Layer Thickness *******

SIDE1: 56.92 um SIDE2: 56.97 um LEH: 56.52 um

Mean thickness: 56.80 um

***** Shimmable Modes ******

Shimmable Mode 1 = 2.76 um Shimmable Mode 2 = 0.04 um

****** Layer Shape *******

Corrected ice amplitudes in microns (from Fourier decomp/for shimming)

	Cos_1	Sin_1	Cos_2	Sin_2	Cos_3	Sin_3
SIDE1:	-0.57	2.91	0.01	-0.18	0.06	0.12
SIDE2:	0.78	2.60	0.07	-0.12	0.07	0.18
LEH:	-0.49	-0.20	-0.05	-0.08	-0.02	-0.05

Corrected amplitude (RMS) per mode in microns

	Mode 1	Mode2	Mode3
Spec (um):	0.52	0.46	0.39
SIDE1:	2.10	0.13	0.10
SIDE2:	1.92	0.10	0.14
LEH:	0.37	0.07	0.04
Side-avg (1 modes):	2.01	0.12	0.12
LEH (m modes):	0.37	0.07	0.04



Limb Analysis: Defects reports

Before Low Mag Image:

After Low Mag Image:

 $K_highMag = 1.69 um$

No low mag data reported.

****** Defects *******

Total standard groove depth = 80.25 umTotal non-standard defect depth = 0.00 um

****** Defects *******

Total standard groove depth = 80.25 um

Total non-standard defect depth = 0.00 um

Largest Defect area = 1261.56 um² from Limb Analysis

K highMag = 1.69 um

 $K_{low}Mag = 1.69 \text{ um}$, based on max groove depth = 26.78 um


Largest Defect area = 1261.56 um² from Limb Analysis

- K value is estimated from Total defect depth (Standard + Non Standard)
- Two K values reported. K_lowMag is refined estimated that depends on the maximum groove found in any view. Use the K lowMag value if available.
- Standard defects are defects that "look like grooves". Non-standard defects are other limb analysis defects (next slide)
- Largest defect can be in either Limb Analysis or Low Mag Analysis



Defects are classified as standard and non-standard

- Standard defects appear to be grain boundary grooves
- Non-standard defects include "mountains"





Limb Analys: Layer thickness

- Reported for each available X-ray view (see section on Analysis)
- Values will be in red if outside the standard +- 1.5 µm range of desired layer thickness
- A "P2" can make the LEH view thickness different from the Side1 and Side 2 views.

****** Layer Thickness *******

SIDE1: 56.92 um SIDE2: 56.97 um

LEH: 56.52 um

Mean thickness: 56.80 um



Limb Analysis: Shimmable Modes and Layer Shape

- Layer shape are the Fourier Cosine and Sine amplitudes, in xray image coordinate system (see section on Analysis).
- Shimmable modes can be controlled with top/bottom temperature difference (Mode 1) or shim heaters on TMP (Mode 2)
- Shimmable amplitude is mean of Side 1 and Side 2 views
- Mode 1 can be controlled in ~ 0.2 μm steps, Mode 2 in ~ 0.1 μm
- Corrected amplitudes are Fourier analysis after defects are removed from the DT edge profile

****** Shimmable Modes *******
Shimmable Mode 1 = 2.76 um

Shimmable Mode 2 = 0.04 um

****** Layer Shape *******

Corrected ice amplitudes in microns (from Fourier decomp/for shimming)

	Cos_1	Sin_1	Cos_2	Sin_2	Cos_3	Sin_3
SIDE1:	-0.57	2.91	0.01	-0.18	0.06	0.12
SIDE2:	0.78	2.60	0.07	-0.12	0.07	0.18
LEH:	-0.49	-0.20	-0.05	-0.08	-0.02	-0.05



Limb Analysis: Layer Shape


- This report compares to the RMS mode amplitude rather than the Fourier Cosine and Sine components.
- First line is the standard upper limit Spec for each mode.
- Red values exceed spec.
- These are still Fourier amplitudes, not Legendre amplitudes.

Corrected amplitude (RMS) per mode in microns

	Mode1	Mode2	Mode3
Spec (um):	0.52	0.46	0.39
SIDE1:	2.10	0.13	0.10
SIDE2:	1.92	0.10	0.14
LEH:	0.37	0.07	0.04
Side-avg (1 modes):	2.01	0.12	0.12
LEH (m modes):	0.37	0.07	0.04




Is there enough time for another attempt? Typical timeline is ~39 hours from attempt start to shot



- Verify no planned ICCS restarts during (Add 2-3 hours if planned)
- Assumes target bay access available to setup for low mag and switch back to standard imaging for shimming
- Assumes seed successfully preserved in Meltback
- Length of timeline can be affected by Facility activities and staff availability –
 Be sure to ask Shot Director or Field Engineer for potential delays!








21

Getting access to CryoData via quicklooks



NIF-0000-00000s2.ppt Author—NIC Review. December 2009







Copyright 2002-2014 Lawrence Livermore National Security, LLC

Version=5.9.16










Copyright 2002-2014 Lawrence Livermore National Security, LLC


Version=5.9.16






Select image view. Three Axes, Side1, Side2, LEH. _RAW images are single images, REGISTERED are an average of 4 exposures









Dashboard reports during layer formation are found under "Reports/Layering States"





First: Select "Taxon Select" CTS|TC00-015|CRYO|LAYERING-CTRL

Second: Select: recipe.dash.report.pdf



ID

TIMESTAMP

Dashboards are stored by time.

Usually want to select the most recent; 5584 05/31/2016 13:04:04.713 recipe.dash.report.pdf dashboard report Download the one at the bottom.

3533 05/31/2016 13:04:04.713 recipe.dash.report.pdf dashboard report Download the one at the bottom.

3533 05/31/2016 13:04:04.713 recipe.dash.report.pdf dashboard report Download the one at the bottom.


3297 05/31/2016 11:05:53.829 recipe.dash.report.pdf dashboard report Download 3325 05/31/2016 11:18:12.453 recipe.dash.report.pdf dashboard report Download 3351 05/31/2016 11:31:05.162 recipe.dash.report.pdf dashboard report Download 3375 05/31/2016 11:42:19.515 recipe.dash.report.pdf dashboard report Download 3401 05/31/2016 11:55:38.678 recipe.dash.report.pdf dashboard report Download 3426 05/31/2016 12:06:52.843 recipe.dash.report.pdf dashboard report Download 3450 05/31/2016 12:18:12.129 recipe.dash.report.pdf dashboard report Download 3476 05/31/2016 12:31:35.712 recipe.dash.report.pdf dashboard report Download 3500 05/31/2016 12:42:49.567 recipe.dash.report.pdf dashboard report Download 353 05/31/2016 13:04:04.713 recipe.dash.report.pdf dashboard report Download 3553 05/31/2016 13:23:46.005 recipe.dash.report.pdf dashboard report Download 3616 05/31/2016 14:24:24.034 recipe.dash.report.pdf dashboard report Download 3648 05/31/2016 14:54:58.083 recipe.dash.report.pdf dashboard report Download 3677 05/31/2016 15:23:28.114 recipe.dash.report.pdf dashboard report Download 3708 05/31/2016 15:53:59.536 recipe.dash.report.pdf dashboard report Download 3740 05/31/2016 16:24:32.381 recipe.dash.report.pdf dashboard report Download 3770 05/31/2016 16:53:13.059 recipe.dash.report.pdf dashboard report Download 3801 05/31/2016 17:23:55.980 recipe.dash.report.pdf dashboard report Download 3833 05/31/2016 17:54:38.932 recipe.dash.report.pdf dashboard report Download 3863 05/31/2016 18:23:15.458 recipe.dash.report.pdf dashboard report Download 3894 95/31/2016 18:53:55.278 recipe.dash.report.pdf dashboard report Download 3926 05/31/2016 19:24:36.556 recipe.dash.report.pdf dashboard report Download 3956 05/31/2016 19:53:20.380 recipe.dash.report.pdf dashboard report Download 3977 05/31/2016 20:12:05 809 recipe.dash.report.pdf dashboard report Download 3983 05/31/2016 20:16:33.113 recipe.dash.report.pdf dashboard report Download 3990 05/31/2016 20:21:06.743 recipe.dash.report.pdf dashboard report Download 4027 05/31/2016 20:41:50.403 recipe.dash.report.pdf dashboard report Download 4063 05/31/2016 21:12:32.138 recipe.dash.report.pdf dashboard report Download 4095 05/31/2016 21:42:08.688 recipe.dash.report.pdf dashboard report Download 4127 05/31/2016 22:12:53.171 recipe.dash.report.pdf dashboard report Download 4157 05/31/2016 22:41:34.897 recipe.dash.report.pdf dashboard report Download

STATE

VALUE

DETAILS






Shortcut to the most recent Dashboard report on the Cryo Quicklooks page



Overview and details of layering




Every layered target has a different experience, but they all suffer the same fate.



A layered target may sit, untouched, for < 12 hours to many days.




NIF cryogenic targets are mounted on the end of a precision positioning boom with integral cryo-cooler





THD – THD/DT ignition target


- 1. Shot temperature: ~18 19 K
- 2. Target will be filled at NIF using the external fuel source (EFS) filled in tritium facility
- 3. Target has 'on-board' reservoir used to fine-tune amount of fuel in capsule
- 4. Hohlraum will be filled with He, tamps wall motion AND conductively cools capsule





THD target has 4 thermometers and 4 heaters


- Sensors and heaters on TMP (Thermal-Mechanical Package) and on the silicon arms
- TMP heaters (HT1 and HT3) are used for P2 shimming
- Arm heaters (HT5 and HT7) are used to set target average temperature and P1 shimming




HT = heater, **TT** = thermometer



DT is a heat source that generates temperature gradients in hohlraum fill gas




- TMP thermometers do not measure the DT temperature directly
- Offset is different for DT and D₂ because
 DT is a heat source, D₂ is not
- Hohlraum size changes temperature offset






Layering from start to shot






The layering process centers around an attempt to isolate a single seed of the proper phase





Layering process temperature vs time






X-ray QA checks target after install in cryotarpos

- Sag in side views is measured relative to inner starburst cutout
 - Capsule center is found, starburst center found. Sag is the difference
 - Errors in machining starburst or positioning of hohlraum can throw off sag measurement. Not much better than +- 4 microns.
 - Sag can change as target is cooled. Usually best to wait until target is cold to act on sag
- Particles on capsule measured using parallax measurement
 - X-ray source moved, displacement of features with respect to the capsule gives relative location
 - Only accurate to +- 1 or 2 mm in Z location, so we can tell if particle is *likely* on capsule, LEH, or shroud windows.
 - Opacity is rough measure of thickness
 - 70% transmission corresponds to ~ 1 μm Au
 - 70% transmission corresponds to ~ 700 μm CH
 - 70% transmission corresponds to ~ 200 μm HDC
 - Dark spots are very likely Au/DU.




X-ray QA image from side view shows circle fits and calculated centers






Example X-Ray QA image






X-Ray QA






Feature position is determined by moving x-ray source and taking advantage of parallax



- Apparent shift relative to capsule gives distance from capsule
- Features on capsule do not move relative to capsule
- Feature on CCD don't move when source is moved
- Maximize displacement of source to achieve best measure of feature location



Example output from parallax measurement



		_							
Side2									
Magnification:	1.93	Image#	2						
Artifact Location: 10:00									
	Artifact		Capsule						
	Х	Υ	X	Y					
Aligned (pix)	322	412	667	226					
Shifted (pix)	323	569	667	387					
Camera Shift (um)	20	3140	0	3220					
Capsule to Source using Magnification (um)	95.54								
X-Ray Source Motions (um)	0.00	342.92		with larger motion.					
Feature to Source (mm)	0.00 97.73								
Capsule to Feature	Negative values are closer to the source.								
distance (mm)	-95.54 2.19 closer to the source.								
Artifact Location:									
	Arti	act	Сар	sule					
	<u>x /</u>	Υ	х ,	Y					
Aligned (pix)									
Shifted (pix)									
Camera Shift (um)	0	0	0	0					
Capsule to Source using Magnification (um)	95.54								
X-Ray Source Motions (um)	0.00	0.00	Use value with larger source motion.						
Feature to Source (mm)	#DIV/0!	#DIV/0!	N1 1"	.1					
Capsule to Feature distance (mm.)	#DIV/0!	#DIV/0!	Negative values are closer to the source.						


Features on side view are often machining burrs on starburst, even though they appear close to capsule

LEH									
Magnification:	1.827	lmage#	2						
Artifact Location:	11:00								
	Arti	fact	Capsule						
	X		X	Υ					
Aligned (pix)	440	328	710	200					
Shifted (pix)	381	226	630	7 3					
Camera Shift (um)	-1180	-2040	-1600	-2540					
Capsule to Source using Magnification (um)	90.44								
X-Ray Source Motions (um)	-160.85	-255.36		with larger motion.					
Feature to Source (mm)	118.76	110.14							
Capsule to Feature distance (mm)	28.33	19.70	Negative values are closer to the source.						
Artifact Location:		1	:00						
	Arti	fact	Capsule						
	Х	Υ	Х Ү						
Aligned (pix)	963	347	710	200					
Shifted (pix)	894	222	630	73					
Camera Shift (um)	-1380	-2500	-1600	-2540					
Capsule to Source using Magnification (um)	90.44								
X-Ray Source Motions (um)	-160.85	-255.36	Use value with larger source motion.						
Feature to Source (mm)	103.35 91.75								
Capsule to Feature distance (mm)	12.91	1.31	Negative values are closer to the source.						

Potentially on capsule Distance measured from center of capsule




Layering from start to shot





Filling is the process of getting fuel from External Fuel Source (EFS) to target reservoir + capsule


- Target reservoir ~ 23-30 K
- Typical pressure in reservoir + capsule is 250 torr after filling
- Capsule filled by adjusting reservoir temperature to increase pressure in capsule, condense liquid
- Manual process to start condensing liquid in capsule





Capsule filling rate control by relative temperature of reservoir and capsule


- Reservoir pressure follows ideal gas law: P ~ T
- Pressure over liquid follows saturated vapor pressure curve for liquid DT





Automated routine Set Inventory tracks liquid level in capsule

- Purpose: Set liquid level that will produce desired solid layer thickness
 - Lookup table translates solid thickness to liquid level
 - Capsule temperature lowered to draw in liquid from target reservoir
 - Capsule temperature dropped rapidly (~ 8 K in ~ 10 seconds) when desired liquid height achieved to stop filling






Preflight

- Purpose: Use the flash-frozen layer from Set Inventory, allow to beta-layer and check for gross P1.
 - Holds temperature for 90 minutes to allow solid to redistribute to nearly final shape
 - Good for determining large P1 (> 5 μ m) to reduce amount of shimming needed in final layer
- Layer is usually too rough to make an adjustment for P2
 - P2 value with no shim current applied is -2.6 μm for a standard target (some target are less). Measurement of rough layer isn't better than this



Get Inventory


• Purpose: Steps temperature rapidly to get approximate melting temperature for this target.





Make Seed


- Purpose: First determine liquid height when fully melted. Then reduce capsule temperature until solidification starts
 - Steps up temperature to verify completely melted. Averages liquid height measurement over several image cycles
 - Then steps temperature down looking for change in liquid height that indicates solid forming
 - Waits 20 minutes for solid to stabilize before proceeding






Meltback


- Purpose: Isolate a small seed crystal in the capsule
 - Steps temperature slowly, compares liquid height to fully melted value determined in Make Seed
 - When liquid height is within 'mtol' (meniscus tolerance), stops increasing temperature and proceeds to Layer Formation





Seed crystal is made by tracking melting in 3 x-ray views









Layer Formation

- Purpose: Slowly cool capsule to form solid layer from seed crystal
 - Standard cooling rate is 0.080 K over 13.5 hours for DT, 0.350 K over 17 hours for HDT.
 - Lost seed if no change in liquid height within 45 minutes of start
 - Restart at MakeSeed if seed is lost
 - Layer is typical stable for first good look at 9 hours into solidification






The layer outcome is reliably predicted starting at 9 hours into the 13 hour script



 High cost to incorrectly throwing out good layers since the mean time to next good layer is 60 hours!



Dashboard view of layer verifies layer evolution is completed with respect to grooves at ~ 9 hours




- P1 and P2 continue to change between hours 9 and 13
- Occasionally layers are still moving between hours 9 and 11, dashboard will show that evolution



Layer will be analyzed at 9 hours and evaluated with respect to rules of engagement going forward

Time Evolution of Layer




- No early aborts before 9 hours, except lost seeds (at 45 min mark)
- NIF staff will run standard layer analysis at 9 hours, send report to shot RI
- Shot RI decides fate of layer
 - Default action of facility will be to continue until end
- Another report at end of layer will be compared to ROE. Facility will act based on ROE




Probability of a layer being accepted* is 23% per attempt

- Data fits geometric distribution showing attempts are independent
- 94% of shots require < 10 attempts
- Average time to accepted layer is 61
 +- 30 hours (2013-2015)
- It is vital to make as many attempts as possible in a given time period
- Must identify bad layers as early as possible in layering attempt
- *Accepted layer does not always mean desired layer
- Only ~10% of layers are "ignition quality", ~ 20% are near-ignition quality






Is there enough time for another attempt? Typical timeline is ~39 hours from attempt start to shot



- Verify no planned ICCS restarts during (Add 2-3 hours if planned)
- Assumes target bay access available to setup for low mag and switch back to standard imaging for shimming
- Assumes seed successfully preserved in Meltback (see next slide)
- Length of timeline can be affected by Facility activities and staff availability –
 Be sure to ask Shot Director or Field Engineer for potential delays!




Lost seed costs 5-6 hours



- Restart next attempt at MakeSeed, increasing allowed amount of remaining solid if appropriate
- Lost seeds usually occur when fuel is > 100 hours old, when melting becomes faster




4 Day layer timeline allows for 2-3 layer attempts



- Typically 22-25 hours from previous shot to fuel loading of target
- 1st layer attempt is usually 24 hours to completion after fuel loading
- Additional full attempts require ~ 18 hours for complete layer
- About 50% chance of getting acceptable layer in 60 hours of "Layering", 84 hours from the last shot
- 7 Day layers allow another ~ 60-65 hours, total layering time ~ 120 hours



Notional Timeline for "4-day" layers



C

У

0

a

0

S

D

0


0

Relative location of the three x-ray imaging systems: Top view



This is viewed from above.

Sides 1&2 images are viewed from camera perspectives.



Side 1 sees: Phi135 and Phi315


Side 2 sees: Phi45 and Phi225

GXD projects into Phi135 view

Add 15 degrees to get to Target Chamber coordinates



LEH view is looking up from below, phi angles are flipped left/right (CryoTarpos image coordinates)





Side 1 sees: Phi135 and Phi315 Side 2 sees: Phi45 and Phi225 GXD projects into Phi135 view


Add 15 degrees to get to Target Chamber coordinates




Three views of fuel surfaces are characterized for shape, roughness and process monitoring













Images are unrolled for mode analysis, groove measurement



- Groove detection is via automated feature detection. Human verifies and removes false detections
- Pixel size is not square in unwrapped images Radius is stretched, angle compressed




Grooves, fourier modes measured in the unwrapped images






Defects are classified as standard and nonstandard


- Standard defects appear to be grain boundary grooves
- Non-standard defects include "mountains"







K is estimated by connecting measured grooves in three x-ray views with Monte Carlo model



- Detect grooves and sum their depths in three views, then derive K from Monte Carlo based on off-line interferometer data
- Refine K based on maximum groove depth, D, from Low Mag + 3 views

$K > = 1.0 \mu m$ is unlikely for grooves <=4 microns deep


• L = $K^{2*}V/A^2$, L = groove length, A = area, V = volume

Total groove length (microns) vs K and Depth								
K(µm)	Depth (µm)	2	3	4	5			
0.5		21,000	9,300	5,220	3,360			
0.7		41,100	18,300	10,230	6,580			
1.0		84,000	37,300	20,800	13,400			

- 2,000 µm long groove is almost certain to be detected in limb views
- Should see ~ 10 grooves 4 μm deep to reach K = 1.0 μm
- Monte-Carlo calculation assumes all possible grooves on the capsule surface, but we can exclude largest with low mag images


Low-Mag Layer Analysis

- Low mag imaging is a screening tool to look for large, short defects that would be missed in the three x-ray views (80% of surface area vs 30% in three limb views).
- Signal to noise increase by averaging 900 images (~3 hours)
- Contrast of feature is used to estimate depth
- Only translate contrast to depth for 'groove' shape, other shapes will result in different contrast
- Cannot tell from LEH view alone if groove is on upper or lower hemisphere of shell






Order and number of shimming adjustments vary with target history






P1 shimming is accomplished by offsetting the temperatures at either end of the hohlraum





P2 shimming is accomplished by applying a radially symmetric current at one or two points along the hohlraum



- Layer is thick at the equator if no shim heat is applied. We call this a negative P2
- Positive P2 results from too much shim power, layer is thin at equator



1.20 0.90 0.60

Convection increases with increasing He gas density, resulting in higher odd modes


- Convective effect scales with He gas density
- Model results from Jim Fair, all amplitudes in microns:

He_density=1.35 g/cc					
P1: P2: P3: P4: P5: P6:	cos 0.00001 -2.44543 0.00008 -0.08511 0.00003 0.00008	sin 1.20133 0.00000 -0.57207 0.00001 0.01959 -0.00019			
P7:	-0.00003	0.01139			
P8:	0.00056	0.00029			

He_density=1.6 g/cc					
	cos	sin			
P1:	-0.00005	1.63379			
P2:	-2.45149	-0.00015			
P3:	0.00008	-0.80137			
P4:	-0.0747	0.00001			
P5:	0.000003	0.02775			
P6:	0.00172	-0.00001			
P7:	0.000003	0.01612			
P8:	0.00028	-0.00003			

P1 due to convection can be shimmed as normal,
 P3 cannot


He velocity magnitude vectors






We found that we get some reduction of P3 by unbalancing shim heater powers

- Convection tends to make bottom of shell warmer, top colder
- Compensate with higher power into top heater, lower power into bottom.
- Adjust TT1-TT3 temperature difference as well.







Nominal vs "P3 control" modes from simulation show reduction in P3 without growth in P2

- Mode amplitudes (microns) with balanced shim heaters:
 a1 = 0.878
 a2 = -0.299
 a3 = -0.907
 a4 = 0.0288
 a5 = -0.0067
 a6 = -0.0034
 a7 = 0.045
 a8 = 0.0028
- Mode amplitudes (microns) with unbalanced shim heaters:
- a1 = -0.01
- a2 = -0.170
- a3 = -0.483
- a4 = 0.048
- a5 = -0.048
- a6 = -0.007
- a7 = 0.0442
- a8 = 0.0017
- Mode 5 is predicted to grow, but still be within requirement
- Experiment matched simulation, typically observe ~ 0.4 micron decrease in P3 in high foot shots with unbalanced heaters
- There are two challenges with P3 control:
 - 1. Increased power to one shim heater can drive larger M1
 - 2. Strong cross-coupling of P2 and P1 shimming



Shimming notes

- P1 shimming is generally uncoupled from other modes; a change in ∆T does not usually change P2, P3.
- A change in shim current can couple to P1
 - Shim P2 can move P1. Amount depends on target, usually < 1 μm</p>
 - P2 is usually within +- 1 micron of 0 during layering, based on previous target types
- A change in shim current can also couple to M1 (The LEH mode 1)
 - Generally M1 amplitude gets higher with increasing shim current
 - Amount is very target dependent
 - Tradeoff is roughly about 1 μm of P2 for 1 μm of M1
- Shim current changes will also change capsule temperature relative to target thermometers
 - About 1 mK/ 1mA² is typical
 - Need to be sure to lower target temperature if shim current is increased after layer has been formed
- If attempting to shim P3, changes in shim current couple 10x more to P1 than P2




Shimming notes (continued)


- Typical target requires a change of ~ 5 mK in ΔT to change P1 by 1 μ m (range is between 4 and 8 for most targets).
 - Typical temperature control is about 1 mK, so typically can get P1 to within +- 0.2 μm
- Usually avoid adjusting shim currents if within +- 0.3 µm because shim current couples to other modes, target temperature
- P1, P2 reported are actually 'Fourier' mode amplitudes, not Legendre modes




Ignition Quality Layers











C140128-AA-2 No grooves; K_std = 0.30073 um








C140128-AA-4 No grooves; K_std = 0.30073 um











Tuning quality layers by standard process

C140109-AA-12 K_std = 1.2849 um; 25 um TGD










C140128-AA-11

K = 0.99 um, 13.7 um TGD










C140220-AA-6 K = 1.26, deep defect in low mag

Capsule












Tuning quality layers by standard process

C140305-AA-1

Aborted for max groove area (450 um2); not yet shimmed










C140513-AA-1

K = 1.18 um, TGD = 20.2 um









C120728-

K =











Layers by standard process that fail specifications



Too many small grooves for ignition quality layers

Layers by standard process that fail specifications


C140610-AA-1 (dev) (not shimmed)






C140809-AA-1 Aborted at 10 hrs (out of 13.5 hrs)








C140610-AA-4

Aborted at 10 hrs (out of 13.5 hrs)







Capsule




Layers by standard process that fail specifications


C131213-AB-1 (10 hrs)










C140109-AA-3








C130427-AA-1








Capsule



Some particularly bad LEH features in the field





Thermal cycling works on layers with one "stuck" defect

LEH view of large defect in layer, before thermal cycle




Groove extends to inner capsule surface

Groove nearly all the way around shell




Thermal cycling works on layers with one "stuck" defect






Unwrapped images, before thermal cycling, defect only in the LEH view





Unwrapped images, after thermal cycling, defect only in the LEH view





Thermal cycling notes

- Thermal cycle works best on layers with one large defect, as though crystal growth was stuck and needed a kick
- Usually one cycle is enough, not much improvement after one cycle
- Layer is partially melted during cycling. The layer needs to redistribute before getting final shape (2-3 hours). The low mode analysis will be incorrect during this 2-3 hour period.
- Thermal cycle often leaves behind bubbles, or holes in the fuel layer.
 Defects can still be large after thermal cycle
- Layer will be better than polycrystalline, able to measure low modes




We have not completely explored polycrystal space

- Summer student began work to characterize:
 - Polycrystal size distribution and variation from layer to layer
 - Size distribution vs quench depth, dwell time,
 - Size distribution vs anneal time/temperature, cycling
 - Still a work in progress
- Additional areas to study
 - Should we start from liquid, or a polycrystal seed
 - Low mode measurement error vs real low mode power
- We can test low-mode measurement error in ITPS
 - Much of summer was spent testing wetted foam, didn't get to test low-mode measurement of polycrystal vs good layer

Polycrystalline layers formed by liquid quench






Optical images, 40 µm CH shell




Polycrystalline layers are difficult to characterize by our standard methods – Edges are often double valued






Stacks of 900 low mag images on single crystal layers show a handful of relatively shallow grooves





In contrast, stacks of 32 polycrystalline images reveal a large number of deep grooves





The fastest we could turn around a poly crystalline layer with the current process is ~8 hrs from fueling.

```
1 hr – inventory set
```

3 hrs – beta layering

4 hrs – shimming

Single attempt (+ 1.5 hrs for each additional attempt)

No low mag characterization (+ 4 hrs)


Shimming would be within +/- 0.5 µm (better number TBD)

Better shimming confidence 0.25 μ m (better number TBD) could be achieved by shimming using a single crystalline layer of TQ or better (+ 24 hrs)

(Recall: ITPS shimming parameters do not directly translate.)



There are several tritium-related "clocks" that could be considered.







- Time from ³He purge in B331
- Time from capsule inventory set
- Time from layer freeze
- Total T soak-time in capsule



The quality of layers does not decrease as fuel ages, but the number of lost seeds does.







We request younger fuel because we do not want to lose seeds




Lost seeds are tied to a change in late melt location and an increase in observed melt rate







2D finite element thermal model that includes evaporation shows equator is the coldest location





Assumptions:

- Tritium beta-decay is a heat source in the liquid
- Constant pressure in gas phase requires liquid—vapor surface to be isothermal
- Evaporation carries heat from bottom of the shell to top
- Energy flux is product of mass flux and Δh_{vap}



2D finite element thermal model that includes evaporation shows equator is the coldest location







Model predicts 1-um thick condensation film and a cold spot at the capsule equator, where seeds occur at early time



Cross diffusion through ³He is one possible cause of cold spot migration





³He generated by decay:

- Concentrates in vapor
- Impedes diffusion of hydrogens
- Reduces condensation
- Results in second cold spot


Model predicts 100-200 hrs for seed location to migrate to north pole






Layer formation process — inventory adjustment

- Capsules are filled with a fill line attached to an internal reservoir in the target assembly
- The internal reservoir is filled from a bottle of gas delivered from LLNL's Tritium facility and attached to the target pylon.





 Adjusting the relative temperatures of the capsule and reservoir changes the fuel volume in the capsule


NIF-0911-22937.ppt 106



Local defects are the primary reason layers fail to meet specifications

Potential mechanisms for defect formation


Multiple Seeds



- Insufficient meltback (crystal #/size)
- Poor starting material (polycrystalline layer quality, FCC phase)

Electrofreezing
Templating
Process optimization


Secondary Nucleation



- Seed crystal orientation & location
- Thermal driving force

Process optimization

Accumulation of Dislocations




- Seed crystal orientation & location
- Thermal driving force

Process optimization



It currently takes around 50 hours to produce an acceptable layer



	K <= 0.922	K accepted
Lost Seed	0.32	0.32
> 1 Seed	0.19	0.19
Max Defect Area	0.24	0.24
Late Aborts (K,Low Modes, LowMag defect)	0.10	0.07
Accepted Layer	0.15	0.19

	K <= 0.922
Lost Seed	0.32
> 1 Seed	0.19
Max Defect Area	0.24
Late Aborts (K,Low Modes, LowMag defect)	0.10
Accepted Layer	0.15

	Number of attempts				
		0.92 < K ≤		Yield, K ≤	Yield, K ≤
	K ≤ 0.92	1.3	K > 1.3	1.3	0.92
Excluding lost seeds	0	6	21	0.42	0.25
Only with mtol ≤ 0.008	9	3	16	0.43	0.32
Grown faster early	7	2	11	0.45	0.35
Grown faster late	2	1	5	0.38	0.25




Could we make decisions earlier based on measurement of defects?

- Standard process: Preliminary look at 10 hrs and another upon completion
- Defect analysis performed on 41 completed layers hourly for t
 5 hrs into the growth process
 - Analysis ignored obvious pole closure features
- Data was compared to final outcomes to determine when reliable predictions could be made




Current seeding process has several failure modes






Seed migration is observed to be faster in layers formed in B581 than in proofing station

- Data suggests that proofing station fill process delivers less ³He (or H₂) to capsule than B581
- We are working to identify the difference






2D finite element model narrows focus of investigation



Mode 1 represented in two coordinate systems

Coordinates used for unwrapping



Spherical-polar "Haan-Mapoles" coordinates (fill tube at phi = 0, theta = 0 at north pole)